


DETAILED PARTS AND ASSEMBLY PROCEDURE



LIST	PART No.	DESCRIPTION	Q'TY
1	E Unit	Pulsarlube E	N/A
2	A005	Reducer, 1/4"F x 1/8" M Adaptor	1
3	B002	Mounting Bracket, "L"Shape	1
4	B057	Washer	1
5	A012	Socket, 1/8"F x 1/8"F Adaptor	1
6	A239	Tube Fitting, Push-In Type, PC8-PT1/8"M	2
7	B051	Self Drilling Screw, #8 X 19	3
8	A212-1	Distribution Tubing, O.D. 5/16"(8mm) Urethan Tubing, 3ft (1m)	1
9	A243	Thread Converter, PT1/8"F X NPT1/8"M (USA only)	1

ASSEMBLY PROCEDURE

1. Install the mounting bracket (3) at a proper location using screws (7). It is good practice to mount the lubricator in close proximity to the bearing to keep feed lines as short as possible.
2. Install the lubricator (1) using the provided reducer (2), washer (4), and socket (5) on the mounting bracket (3). Be sure to position the lubricator so that it will allow for easy adjustments.
3. Insert the push-in fitting connector (6).
4. Measure and cut the tube (8) to the desired length. Be sure the tube ends are cut clean and perpendicular and that no damage is present on the outside surface.
5. Insert the tube into the push-in fitting connector (6) for a quick and easy leak-proof connection.
6. Install lubricator and follow lubricator operation instructions on user manual.

COMMENTS

1. All Parts should be assembled tightly with PTFE tape.
2. For optimal performance with remote installation kits, using an NLGI #1 grade grease is recommended.
3. If the bearing lube point is NPT, use the thread converter (9).

Note : All parts above are Metric thread.